


Steigen


AUTOMATED LAUNDRY SYSTEMS



Solar Evo Series User Guide

A HANDHELD WIRELESS REMOTE CONTROL FOR BETTER EXPERIENCE

It's now easier than ever to lift your heavy laundry without breaking a sweat. Simply press the buttons to interact with your Steigen.



1. Up

Press to lift or pause the system.

2. Down

Press to lower or pause the system.


3. Lighting

Press to turn on and off the LED lights.


HANDLING BIGGER ITEMS e.g (BED LINEN)

Steigen laundry system is specially designed for heavy-duty usage. When handling bigger items, like bed linen, you can lower the 2 poles in the middle by gently lifting it out of the cache.

When not in use, you may return the poles to their original position and utilise them for regular laundry drying needs.





Original position for normal clothing




Lowered poles to handle bigger items

BUILT-IN PLASTIC CLOTHES CLIPS

With our Solar Evo series, we provide poles that come with built-in plastic clothes clips where you can hang the smallest of items. Simply slip your garments upwards to keep it in place and tug it downwards to remove it.



Alternatively, you can use the holes of the clothes clips to hang more garments.



PAIRING REMOTE FOR THE FIRST TIME

Follow the below 2-step guide to pair/sync the remote with your Steigen system:

1. Turn off your system's main power switch (wait 5 - 10 seconds) and turn it back on.

**Once the system powers on, you will hear a beeping melody..*


2. Immediately press the “Light” and “Up” buttons on the remote control at the same time, until you hear another beep sound to release.

Important: Do not wait for the beeping melody to finish before pressing the buttons.

3. Hearing a beep indicates that pairing was successful.

The remote control is now ready to use with the system.

CHANGING REMOTE BATTERY (FOR SOLAR EVO SERIES)



Each remote control requires 2 pieces of AAA batteries. Flip to the back of the remote control and remove the back cover.

Lift the back panel up to insert the batteries.